



DEKSWOOD FACT SHEET

Description

Dekswood is a unique blend of detergents and an effective, economical and easy to use timber cleaner and brightener. It will also clean concrete, sandstone, slate, aluminium, vinyl, plastics and fibreglass. *Dekswood* does not contain bleach.

Purpose

Dekswood will restore a like-new look to dirty, discoloured wood surfaces without bleaching. Removes rust stains, water marks and concrete & lime burns. *Dekswood* does not remove paint or oil stains.

Drying Time

Allow 3 good drying days for wood before over coating with paint or stain. Other surfaces can be treated as soon as they are dry. For protective timber coating we recommend *CWF-UV* for all exterior softwoods.

Container Size

Dekswood is available in 1, 4, and 20 litres containers.

Application

Thoroughly wet the area to be cleaned, apply *Dekswood* with a stiff bristle brush, leave for 15-20 minutes and rinse thoroughly.

Coverage

Dekswood is highly concentrated. One part *Dekswood* mixed with 4 parts water, will clean from 10 - 20 square metres per 4 litres of mixed product. Severe problems and rust marks will need a stronger solution. .

Clean-up

Water.

Safety Directions

Dekswood contains 16% oxalic acid. Harmful or fatal if swallowed. If splashed in eyes, flush with copious amounts of fresh water and seek medical attention. Wear protective clothing and rinse skin thoroughly if splashing occurs. Protect areas, which do not need cleaning as well as shrubs and plants.

Waste Disposal

Dispose of in accordance with local regulations.